

# 7MM VT PRUSIK

REV080822

The 7mm VT Prusik was designed for use on smaller diameter ropes. This specialty design features a tough, heat resistant Technora aramid sheath over durable nylon core strands. The core in this kernmantle design keeps the VT from flattening and binding up. A computerized large gauge sewing machine is used to bar tack a devilishly strong stitch with custom thread. This thread/stitch combination yields superior strength and overall durability. Manufactured in the U.S.A.

The VT Prusik is a versatile open-end Prusik. Use to tie: Symmetric Prusik, Asymmetric Prusik (Schwabisch/Distal), Valdotaín Tresse, French Prusik.

The VT performs well when used for ascending, self-belay while rappelling, as a traveling rope grab, or in conjunction with a prussic minding pulley in haul systems.

For use on personal ropes 8mm - 9.5mm in diameter

## **Specifications:**

- Heat resistant Technora aramid sheath
- Kernmantle design prevents core flattening and binding
- Manufactured in the U.S.A.

## **Dimensions:**

- Weight: 1.6 oz.
- Length: 33 in.
- Diameter: 7 mm

## **7mm VT Prusik**

Item #	NSN#
90-4050	



**NORTH AMERICAN RESCUE®**  
[www.NARescue.com](http://www.NARescue.com) • 888.689.6277

**PRODUCTS**  
WITH A  
**MISSION®**