



# 8MM HAVOC Assault Rope

The new **8mm HAVOC** is the latest addition to North American Rescue's **Pegasus Rope Series**. **NAR & Edelrid**, the industry

leader in rope manufacturing with 150 years of experience, have joined forces with multi-disciplinary vertical specialists to innovate **the most tenacious small diameter rope on the market today** – engineered to counter the most severe environmental pathologies found throughout full-spectrum operations... whether at work or at play.

The unique material engineering of the 8mm HAVOC core, specifically it's **Innegra™ Braided Fiber Core Integration**, provides **superior durability, low fatigue** properties, an **extremely low specific gravity**, and **superior resistance to the harshest contaminants** (acids, bases, and organic solvents). The novel tensioning and fiber refinement techniques utilized within the **12-braid Innegra™ core amplifies its overall robustness** and **resilience** providing an operational rope which acts as a counter-measure to anticipated environmental challenges.

This specialized core of the 8mm HAVOC is protected by a higher density, precision double braided **Technora sheath** to synergistically interface with the core for **optimized strength, elongation, decreased creep, heat resistance, and operational safety**. To reinforce the **abrasion resistance, cut resistance, and overall durability**, the 8mm HAVOC's sheath was bulked up to a **52.5% sheath ratio**.

**Engineered to counter the pathologies innate to the following environments and/or mission sets:**

- **Mountain/Rough Terrain Movement & Evacuation**
- **Urban Access, Extraction, & Rescue**
- **Waterborne/Maritime Access & Rescue**
- **Cave/Subterranean Response**
- **Snow/Ice Rescue**
- **Shipboard Response, Rescue, & Evacuation**
- **Canyon Movement & Rescue (Class B and C)**
- **Confined Space Rescue**
- **Wilderness SAR**
- **Wildland REMS**

**8mm HAVOC Assault Rope**

LENGTH	ITEM #
50 ft	90-8501
75 ft	90-0403
100 ft	90-1402
150 ft	90-0404
200 ft	90-2402
300 ft	90-3402

**Wreak HAVOC, with confidence!**

**EDELRID**

in partnership with

**NORTH AMERICAN RESCUE®**

[www.NARescue.com](http://www.NARescue.com) • 888.689.6277



REV12222

**Innovative Synergy of 2 unique Fibers engineered for unmatched Confidence & Resilience from Ropes in Challenging Environments...**

**INNEGRA CORE**



**52.5% Technora® Sheath**

## Special Features:

### CORE

- **Innegra™** Lightest Weight Structural Fiber on the market with a very Low Specific Gravity
- Hydrophobic
- Resistant fo Harsh Contaminants
- Low Flex Fatigue
- Superior Durability
- Meets EN 564

### SHEATH

- **52.5% Technora Sheath Ratio (by weight)**  
**The most robust on the market!**
- Resistant to Cuts, Abrasion & Heat
- Optimized Strength
- Decreased Creep
- Increased Durability & Safety

### Specifications:

- Diameter: 8 mm
- Weight: 2.9 lb/100 ft
- Elongation: 300 lb: 3.58%
- 3-Sigma MBS: 5,615 lb (24.5 kN)
- Fibers (Core/Sheath): Innegra™/Technora®
- Sheath Ratio (by wt.): 52.5%

