

EDELRID HMPE CORD BLUE SLING - 120CM

REV041724

High Strength & Capacity HMPE sewn sling....

Sewn sling made of high-strength kernmantle material. The tightly braided polyester sheath is abrasion resistant, stiffens the sling to make it easier to create threads, and generates a good clamping force when used as a prusik sling. The HMPE cord is extremely strong and offers outstanding permanent flexural strength. HMPE delivers a significantly higher breaking strength than conventional slings. For use as a full-spectrum anchor, harness extension, alternate prusik, and as a canyon quickdraw for RTR (Rig to Raise) conversions.

Features:

- Load capacity [Kn]: 22
- CE marking: CE 0123
- Certification: EN 354
- Certification: EN 566 to Specs
- Made of high-strength kernmantle material
- Particularly stiff and perfect for threads
- 30 cm variant is particularly suitable for use as a prusik sling

Dimensions:

- Width: 0.24 in. (6mm)
- Weight: 0.78 oz (22gm)



NORTH AMERICAN RESCUE®

www.NARescue.com • 888.689.6277

PRODUCTS
WITH A **MISSION®**