

PETZL® REVERSO 4 *Belay/Rappel Device*

REV062823



RESCUE

Multi-Purpose Belay/Rappel Device...

Ultra-light, multipurpose, hot-forged aluminum belay/rappel device that regulates the amount of braking friction on the rope according to its diameter and condition; Reverso mode.

V-shaped friction channels with asymmetrical lateral grooves adapt the friction to the type of rope for better control. Reverso mode for belaying one or two seconds with assisted braking.

Features:

- Ultra-light, multi-purpose, hot-forged aluminum belay/rappel device
- Regulates the amount of braking friction on the rope according to its diameter and condition

Dimensions:

- Rope Size:
 - Half Ropes & Twin Ropes ≥ 7.5 mm
 - Single Ropes ≥ 8.9 mm
- Weight: 59 g

Petzl® REVERSO 4

CE

ITEM #	NSN #
ZZ-0546	



NORTH AMERICAN RESCUE®

www.NARescue.com • 888.689.6277

PRODUCTS
WITH A
MISSION®