

AUTO-LOCK CARABINER - PIRATE

REV071423

As an HMS, or pear-shaped carabiner, the Pirate easily accommodates the use of a wide range of gear, webbing or ropes - either as a belay biner at the harness, or as a connector in a system. The Pirate's robust 0.5" diameter round frame will endure abuse from dirty ropes and metal connectors far beyond stamped carabiners with thin edges. The Pirate's durability matched with Rock Exotica's build quality ensures an impressive service life for the working professional or recreational enthusiast.

Features:

- Wide top radius allows munter hitch belay, or the connection of multiple items
- Durable 0.5" round-stock frame
- Snag-resistant keylock nose design
- Large and ergonomic angled gate opening
- Machined frame ensures tight tolerances and smooth operation

Specifications:

- Gate: Auto-Lock
- Ref #: C1 A
- Gate Opening: 1.0" (25 mm)
- Certification: CE

Strength:

- MBS Major: 26 kN
- MBS Minor: 12 kN
- MBS Open: 7 kN

Dimensions:

- Height: 4.2 in. (107 mm)
- Width: 2.8 in. (71 mm)
- Weight: 3.09 oz (87 gm)



Auto-Lock Carabiner - PIRATE

Item #	NSN#
90-4003	



NORTH AMERICAN RESCUE®
www.NARescue.com • 888.689.6277

PRODUCTS
WITH A
MISSION®