

TACTICAL HARNESS LEG LOOPS *Coyote*

REV101923

A multi-disciplinary tactical harness for use in various operational environments.

NAR & Edelrid have joined forces to bring the new Edelrid Tactical Harness to the US. Edelrid is the industry leader with 150 years of experience in rope and climbing gear manufacturing. A full customer solution, the tactical harness system is not only an emergency harness, but it can also be fully used as a climbing harness and can be worn comfortable loaded or unloaded.

Key Differentiators: single tie-in attachment point, sized to integrate into standard pant loops, no carabiner needed to connect belt to leg loops, triple lock safety buckle, integrates into or under any battle belt, built in indicator threads inside webbing for visual on wear, sleek, smooth and easy to use.

Features:

- In combination with belt certified according to EN 12277 Typ C
- Leg Loops - ONLY
- Ultra-light design made from load-bearing edge bindings with breathable mesh
- Are adjustable and fully removable with Triple Lock buckle
- Have elastic hip attachment strap keeping leg loops in place
- Have Red indicator threads inside webbing to show end of the harness service life

Triple Lock Buckle:

- The Triple Lock buckle is the safest and most innovative buckle in Edelrid's line of products
- Triple buckle requires 3 step release, unload (press bar release) for webbing to loosen, press the large release button, push buckle together and angle the buckle outward to release catch from buckle closure. *(see educational materials below for more data and visuals)

- Under load the buckle cannot open inadvertently but with release bar can be loosened not under load to aid in buckle release
- Although a very safe buckle it is still very fast and effective to use
- Large push button release can be manipulated with gloves on
- The webbing release bar prohibits loosening of webbing during load and also when unloaded
- All homogenous metal parts to avoid corrosion
- Saltwater resistant

Dimensions:

- Weight: 0.60 lbs
- Size: One size fits most



Tactical Harness Leg Loops

COLOR	ITEM#
Coyote	90-4029



NORTH AMERICAN RESCUE®

www.NARescue.com • 888.689.6277

PRODUCTS
WITH A **MISSION®**