

DESCENT DEVICE *MAGO 8*

REV082323

Ultra-light figure 8 descender has a compact design with minimal weight and a small pack size for use on low-diameter ropes. The special geometry with little horns enables several different friction modes, making it possible to precisely adjust the abseiling speed. The plate function brings up a second as a doubled rope with the Rap Line II.

Features:

- Ultra-light, compact design for minimum weight and a small pack size
- Plate function for bringing up a second as a doubled rope with the Rap Line II
- Special geometry with little horns for implementing several different friction modes
- Ideal for use with the Rap Line II
- CE marking: CE 0123

Dimensions:

- Measurements: L 4.125 in. x W 2.75 in. x D 0.25 in.
- Weight: 1.34 oz (38 g)

Descent Device - MAGO 8

ITEM#

90-4026



NORTH AMERICAN RESCUE®

www.NARescue.com • 888.689.6277

PRODUCTS
WITH A
MISSION®