

BELT THROW BAG *Water Rescue*

RESCUE

REV031924

Multipurpose Water Rescue Solution Designed For Easy Deployment and Retrieval...

The Water Rescue Belt Throw Bag from NAR® is a multipurpose water rescue solution designed for easy deployment and retrieval for rescuers. The quick release reverse tapered throwbag holds 60 ft of 7.5 mm Triton Pegasus Rope® which is rated at over 3,300 lb. Rope features two colored runners and 1 reflective runner for increased operational visibility and nighttime reflectivity. The Kit's reverse tapered design allows for rapid packing of the Triton rope and a slim profile for users.

The adjustable belt features 2 in. quick release strap, 1.5 in. plastic cam buckle, and red toggle ball for easy ID/throwbag release during water rescue work or paddling. The belt throw bag features a cinch top with 550 Cord, plastic cordloc & hook-and-loop top flap. Also included is an external gear pouch with moveable MOLLE attachment system located on belt. This gear pouch, secured with zipper top closure and loop Velcro® patch for end user custom ID, keeps your recovery hardware at quick reach even when throw bag is deployed.

Features:

- Multipurpose water rescue solution designed for easy deployment and retrieval for rescuers
- The quick release reverse tapered throw bag for rapid packing of the Triton rope and a slim profile for users
- Two colored rope runners and 1 reflective runner for increased operational visibility and nighttime reflectivity
- 2 in. adjustable belt with quick release strap, 1.5 in. plastic cam buckle, red toggle ball for easy ID and throwbag release during water rescue work or paddling
- Additional external gear pouch included on belt with moveable MOLLE attachment to keep recovery hardware at quick reach even when throw bag is deployed
- Included Cinch top with 550 Cord, plastic cordloc and hook-and-loop top flap



Rope and bag not pre-configured for use



Dimensions:

- *Bag*
L 11 in. x W 4.5 in. x D 4 in.
- *Pouch*
L 5.5 in. x W 5 in. x D 2 in.
- Weight: 2 lb 2 oz

Water Rescue Belt Throw Bag

ITEM #	NSN #
90-0065	----



NORTH AMERICAN RESCUE®
www.NARescue.com • 888.689.6277

PRODUCTS
WITH A MISSION®



QTY 1
Nylon Bag
w/ Belt - ORG

QTY 1
Nylon Gear
Pouch - ORG

QTY 1
7.5mm Triton
Rope - 60 ft