

# 10 IN. X 12 IN. NIJ LEVEL III+ UHMWPE PLATE ARMOR

REV090624

## MULT-CURVE - SHOOTER CUT



Made with a ceramic front face and UHMWPE, this premier NIJ level III certified plate is lightweight and provides outstanding ballistic protection against rifle threats. It is NIJ special threat tested specifically to protect against so called armor piercing rounds such as the 5.56 X 45mm M855 green tip and 7.62 x 39mm BZ API. This stand-alone, multi-hit plate weighs only 4.3 lbs for all day comfort. Its slim design allows it to be easily slipped into the plate pocket of the NAR responder vest without needing to take the vest off. Its durable construction is backed by a 10-year warranty.

All NAR® Responder Ballistic PPE vests, carriers and armor components are free of polyfluoroalkyl substances (PFAS).

### Features:

- Made with Ceramic and Durable UHMWPE (Ultra High Molecular Weight Polyethylene) materials which are processed to create a lighter, thinner, high performing plate
- High Performing NIJ 0101.06 - Certified Level III
- User-friendly design fits to the contours of the body for maximum safety and comfort
- Rugged, reliable, and stress fracture resistant
- Fully sealed to protect against liquids, chemicals, and harsh elements
- Multi-hit Rifle Defense Capability
- Shooter's cut Single Curve
- Stand Alone
- 10 year warranty
- **PFAS Free** - made *without* polyfluoroalkyl substances

### Specifications:

- Dimensions:  
W 10 in. x H 12 in. x D 1 in.
- Weight:  
4.3 lb (*Shooters Cut*)

### Level III+ UHMWPE Plate Armor - Shooter Cut

ITEM #	NSN #
70-0428	----

*For New York customers, purchase of this product is limited to eligible professions. Please contact Customer Service with any questions.*

### Special Threat Performance:

- 5.45mm x 39mm, 54gr (MSC) 7N6
- 5.45mm x 39mm, 55gr 7N10
- 5.56mm x 45mm 55gr. M193 Ball
- 5.56mm x 45mm 62gr. M855 (Green Tip)
- 7.62mm x 39mm 123gr MSC
- 7.62mm x 39mm 121gr BZ API
- 7.62 X 54Rmm 148gr LPS



**NORTH AMERICAN RESCUE®**

www.NARescue.com • 888.689.6277

**PRODUCTS**  
WITH A **MISSION®**